

QUICK CONNECT GUIDE SET-TOP BOX

WITH WIRED CONNECTION

For detailed information on how to use your Set-Top Box guide including DVR functions, Parental Controls and more, visit execulink.ca/stb-guide.

NEED HELP?

CONTACT US AT 1.866.706.2053
OR EXECULINK.CA/SUPPORT

STEP 2: CONNECT TO SET-TOP BOX

1. Move the set-top box near to your desired TV.
2. a) If you are a new customer, plug the Ethernet cable from your Internet installation into the back of the set-top box.

OR

b) If you are replacing your set-top box, check if your connection has been set up via coaxial cable or Ethernet. Plug either cable into your new set-top box. If using the coaxial cable, make sure it is threaded properly and tightly.



OR



STEP 4: SETUP REMOTE CONTROL

1. Open the battery cover by pressing down on the battery cover latch and sliding it off.
2. Insert the batteries, matching the + and - marks on the batteries with the interior of the remote control.
3. Snap the battery cover to close.



NEED HELP?

CONTACT US AT 1.866.706.2053
OR EXECULINK.CA/LINKTVSUPPORT

STEP 1: DOUBLE CHECK

Make sure you have the following components available to complete the setup of your TV service.

Set-Top Box & Power Adapter

Note: Your Set-Top Box may look slightly different than the one pictured here.



Remote Control & Batteries (x2)



HDMI Cable




Ethernet Cable



STEP 3: CONNECT TO TV & POWER

1. Connect the HDMI cord into the HDMI port in the back of the Set-Top Box.
2. Plug the other end of the HDMI cable into an HDMI port on your TV.
3. Plug the power cord into the back of the Set-Top Box and the other end into a wall outlet.



STEP 5: TURN ON TV

Turn on the TV and select the correct video input.

DONE!



For detailed information on how to use your Set-Top Box guide including DVR functions, Parental Controls and more, visit execulink.ca/stb-guide.